



# GOTTWALD HMK 280 E

radius	Capacities						
							
	normal load	grab *	spreader	special load	heavy load	spreader	grab *
	66 2/3%	50 %	66 2/3 %	75 %	66 2/3 %	66 2/3 %	50 %
(m)	(t)	(t)	(t)	(t)	(t)	(t)	(t)
11-16	63,0	32,0	35,0	100,0	100,0	35,0	32,0
17	63,0	32,0	35,0	100,0	100,0	35,0	32,0
18	63,0	32,0	35,0	100,0	100,0	35,0	32,0
19	63,0	32,0	35,0	100,0	100,0	35,0	32,0
20	63,0	32,0	35,0	100,0	100,0	35,0	32,0
21	63,0	32,0	35,0	100,0	100,0	35,0	32,0
22	63,0	32,0	35,0	100,0	95,9	35,0	32,0
23	63,0	32,0	35,0	98,3	89,5	35,0	32,0
24	63,0	32,0	35,0	91,7	83,5	35,0	32,0
25	63,0	32,0	35,0	86,2	78,5	35,0	32,0
26	63,0	32,0	35,0	81,3	74,0	35,0	32,0
27	63,0	32,0	35,0	76,3	69,5	35,0	32,0
28	63,0	32,0	35,0	72,5	66,0	35,0	32,0
29	62,7	32,0	35,0	68,9	62,7	35,0	32,0
30	59,5	32,0	35,0	65,4	59,5	35,0	32,0
31	56,6	32,0	35,0	62,2	56,6	35,0	32,0
32	53,9	32,0	35,0	59,2	53,9	35,0	32,0
33	51,4	32,0	35,0	56,5	51,4	35,0	32,0
34	49,0	32,0	35,0	53,8	49,0	35,0	32,0
35	46,5	32,0	35,0	51,1	46,5	35,0	32,0
36	44,5	32,0	35,0	48,9	44,5	35,0	32,0
37	43,0	32,0	34,4	47,2	43,0	34,4	32,0
38	41,3	30,8	32,7	45,4	41,3	32,7	30,8
39	40,0	29,7	31,4	43,9	40,0	31,4	29,7
40	38,5	28,6	29,9	42,3	38,5	29,9	28,6
41	37,1	27,7	28,5	40,8	37,1	28,5	27,7
42	35,8	26,7	27,2	39,3	35,8	27,2	26,7
43	34,4	25,8	25,8	37,8	34,4	25,8	25,8
44	33,3	25,0	24,7	36,6	33,3	24,7	25,0
45	32,0	24,2	23,4	35,2	32,0	23,4	24,2
46	30,8	23,1	22,2	33,8	30,8	22,2	23,1
47	29,7	22,3	21,1	32,6	29,7	21,1	22,3
48	28,5	21,4	19,9	31,3	28,5	19,9	21,4
49	27,3	20,5	18,7	30,0	27,3	18,7	20,5
50	26,0	19,5	17,4	28,6	26,0	17,4	19,5

Spreader weight 8,6 t